





Lift up the paper weight
and insert paper into the
machine.





Set paper weight on top of paper.



Push operating lever
toward the rear of the
machine.



Let the operating
lever come forward.



As the operating lever comes back toward the operator, the stabber goes into the paper stack and starts picking a lift of paper.



Remove paper lift & repeat.



Adjust thickness of paper lift using the adjustment knob.

